





All manual gates (excluding close boarded plot pedestrian gates) are to be constructed to avoid trapping/crushing zones should the gate be opened or closed inadvertently, for instance by the wind or by another person. When open the gate should be limited to a maximum 90 degree opening by means of a restricting cleat fixed to the post (hinge side). The hinge should allow for a minimum 50mm clear gap between the gate and post when open and closed to prevent entrapment.

